





EXAMPLES OF USE STANDARD CONFIGURATION




Dimension in mm



Example with nut



Example with stud



NO

You can't insert nuts or studs upwards if $D1$ is wider than 4 mm



Via Martino Ferraro, 3
54100 Massa (MS) ITALY
tel. +390585-856125
fax. +390585-851074